

PowerPad 160/120/80 Compatibility

6/6/2003

Computer Manufacturer	Brand	Model	Power Cable Number	PowerPad Model	Note
Acer	AcerNote	350 series, 370 series, 380 series(light), P100(light), 850C	A55	D	*1,*6
	AcerNote	367, 390 series	A33	D	*1,*6
	Extensa	355, 500, 501 series, 502, 503 series, 600, 610 series	A55	D	*1,*6
	Extensa	360, 390 series, 900	A33	D	*1,*6
	LT300	LT300	A33	A	
	TravelMate	330	A11	A	
	TravelMate	340, 350, 505, 520, 600, 730	A55	A	
	TravelMate	220, 506, 507 series, 524 series, 630	A55	D	*1,*6
Apple	iBook	G3	A91	C	*1,*6
	PowerBook	G3	A90	C	*1,*6
	PowerBook	G4	A91	C	*1,*6
Compaq	Armada	100S	A22	A	
	Amada	1120, 1125, 1130	A11	D	*1,*6
	Amada	2940	A33	D	*1,*6
	Armada	M700 Series	A44	A	
	Armada	1100, 4100, 4200	A11	A	
	Armada	E Series	A44	A	
	Armada	V 300	A44	A	
	EVO	N610C	A44	A	*3
	EVO	N150, N400c, N600c	A44	D	*1,*6
	EVO	N160, N180	A33	D	*1,*6
	LTE	5000, 5150, 5200, 5250, 5300, 5380, 5400, 5480, 6000	A11	A	
	Presario	700 Series	A33	A	
	Presario	705xx	A33	A	
	Presario	300, 1000, 1200, 1600, 1700, 1800	A33	A	
	Prosignia	150, 170, 190	A44	A	
CompuSmart	SmartLine	CSL44, CSL46, CSL47, CSL58, CSL61	A33	D	*1,*6
Dell	Inspiron	2500, 2600, 2650, 3700, 3800, 4000, 4100, 5000, 5000e, 7500, 8000, 8100, 8200	A66	D	*1,*6
	Inspiron	3000, 3200, 3500, 7000	A33	D	*1,*6
	Latitude	CXXX, LCP, CP, CPi, CPt, CPx, CS, CSx, Xpi	A66	D	*1,*6
	Latitude	433, 450, 475, LX, LX4100	A55	D	*1,*6
Electrovaya	Scribbler	SC300, SC500, SC800			
Fujitsu	LifeBook	S, B, P, A, E	A77	A	*4
	Lifebook	C2010, C2110, C2111, E7010, E7110, A1010	A77	D	*1,*6
	PenCentra	130, 200	A77	A	
	Point	1600	A77	A	
	Stylistic	500, 1000, 1200, 2300, 3500, LT C-500, LT P-600	A77	A	
	Stylistic	3400	A78 (A73)	A	*1,*2

*1 Electrovaya supplied AC adapter is required to charge the PowerPad

Models in Bold are new.

*2 Notebook cannot be operated from the PowerPad while charging using the Electrovaya AC adapter

*3 Notebook supplied charger should not be used to simultaneously charge both the PowerPad and the notebook.

*4 Excluding E - 6624/34/44/54/64

*5 Excluding P4 models

*6 Not available in PowerPad 80 Model

PowerPad 160/120/80 Compatibility

6/6/2003

Computer Manufacturer	Brand	Model	Power Cable Number	PowerPad Model	Note
Gateway	Solo	200, 510, 600, 3450, 5300, 5350, 9500, 9550	A11	A	
	Solo	400, 9550, 1100, 1150, 1200, 1400, 1450, 2000, 2100, 2150, 2200, 2300, 2500, 2550, 3100, 3150, 5100, 5150	A11	D	*1,*6
HP	Omnibook	500, 900, 2100, 3000, 4000, 6000, 7100 series, XE, XE2, XE3	A33	D	*1,*6
	Omnibook	4000 Series	A55	D	*1,*6
	Pavillion	ZE, ZT, ZU series, N3000 series, N5000 series, XH176, XH555	A33	D	*1,*6
IBM	"A" Series	A20 2628 / 2629, A30	A33	A	*5
	"A" Series	A30 (P4 models), A31	A33	D	*1,*6
	"R" Series	R30, R31	A33	A	
	"R" Series	R32, R40	A33	D	*1,*6
	"T" Series	T20 2647, T21, T22, T23	A33	A	
	"T" Series	T30	A33	D	*1,*6
	"X" Series	X20, X21, X22	A33	A	
	"X" Series	X30, X31	A33	D	*1,*6
	I-series 2611	1400, 1500	A11	A	
	I-series 2621	1400, 1420, 1460, 1480, 1500	A33	A	
	I-series	1700, 1720, 1721	A33	A	
	ThinkPad	240, 290, 365, 380, 385, 390, 560, 570, 600, 700, 701, 770, Transnote	A33	A	
Kiwi	Panel PC	686T	A33	A	
Micro	Trek	2, NX, LT	A33	D	*1,*6
NEC	Ready	220T, 230T, 330T, 340T, 360T	A55	D	*1,*6
	Versa	2400 series, 2500 series, 5000 series, 550D	A33	D	*1,*6
Panasonic	ToughBook	CF01, CF07, CF17, CF25, CF27, CF28, CF33, CF34, CF35, CF37, CF45, CF47, CF61, CF62, CF71, CF72, T1	A78 (A73)	B	*1
Sharp	PC	3000 series, 8000 series, 9000 series, S400	A55	D	*1,*6
Sony	Vaio	PCG-F590, PCG-R505GL	A77	D	*1,*6

*1 Electrovaya supplied AC adapter is required to charge the PowerPad

Models in Bold are new.

*2 Notebook cannot be operated from the PowerPad while charging using the Electrovaya AC adapter

*3 Notebook supplied charger should not be used to simultaneously charge both the PowerPad and the notebook.

*4 Excluding E - 6624/34/44/54/64

*5 Excluding P4 models

*6 Not available in PowerPad 80 Model

PowerPad 160/120/80 Compatibility

6/6/2003

Computer Manufacturer	Brand	Model	Power Cable Number	PowerPad Model	Note
Toshiba	Libretto	100, 110	A85 (A83)	B	*1,*2
	Libretto	50, 70	A23	B	*1,*2
	Portege	3010, 3015, 3020, 3025, 3110, 3120, 3440, 3480, 3490	A85 (A83)	B	*1,*2
	Portege	300, 320, 610, 620, 650, 660, 1400, 2000, 4000, 4005, 4010, 7000, 7010, 7020, 7030, 7140, 7200, 7220	A23	B	*1,*2
	Satellite	1605, 1625, 1675, 1695	A33	B	*1,*2
	Satellite	200, 220, 225, 300, 310, 305, 315, 320, 325, 330, 335, 1555, 1400, 1800, 2060, 2065, 2095, 2100, 2105, 2140, 2180, 2210, 2230, 2250, 2280, 2400, 2410 , 2500, 2505, 2510, 2515, 2520, 2525, 2540, 2545, 2590, 2595, 2610, 2615, 2655, 2675, 2715, 2775, 2800, 2805, 4000, 4010, 4015, 4020, 4025, 4030, 4060, 4070, 4080, 4090, 4100, 4280, 4600, 5000, 5100, 5005, 5504, T200	A23	B	*1,*2
	Satellite	1200, 1730, 1735, 1750, 1900, 3000	A33	D	*1,*2,*6
	Satellite	T1900, T2400, T4500, T4600, T4700, T4800, T4850, T4900	A11	D	*1,*6
	Satellite	T4800CT, T2850CT	A55	D	*1,*6
	Satellite Pro	440, 445, 460, 465, 470, 480, 490, 490X, 4200, 4220, 4260, 4280, 4300, 4600, 6000, 6100, TE 2000, TE 2100	A23	B	*1,*2
	Satellite Pro	3000	A33	D	*1,*2,*6
	Tecra	520, 530, 550, 700, 710, 720, 730, 730X, 740, 750, 780, 8000, 8100, 8200, 9000, 9100	A23	B	*1,*2
	Tecra	8110	A85 (A83)	B	*1,*2
Twinhead	SlimNote	910CV, 9133 series, 9150TZ, 9166TZ, VX, VXE, VXE3	A33	D	*1,*6
	SlimNote	5, 5100 series, 550S, 575, 600D, 6100 series, 8100 series, 875TX, 890 series, 9 series, 9100	A55	D	*1,*6
TTX	Performance	P2000	A33	D	*6
Viewsonic	ViewPad 1000	ViewPad	A33	B	*1
WalkAbout	Hammerhead	HH3	A33	B	*1
WinBook	Winbook	FX, XP5 Pro	A55	D	*1,*6
	Winbook	Si Series, Si2 850, XL, XL 300TFT, XLI, X4 , XP, XP5, Z1, Z1 850	A33	D	*1,*6
	Winbook	X1	A33	A	

*1 Electrovaya supplied AC adapter is required to charge the PowerPad

Models in Bold are new.

*2 Notebook cannot be operated from the PowerPad while charging using the Electrovaya AC adapter

*3 Notebook supplied AC adapter should not be used to simultaneously charge both the PowerPad and the notebook.

*4 Excluding E - 6624/34/44/54/64

*5 Excluding P4 models

*6 Not available in PowerPad 80 Model